

7.4 – Touchscreen

Your ecube touchscreen offers a variety of interesting features. Use pinch gestures to zoom in or out (as your fingers move apart, the screen zooms in).


7.4.1 – Camera

The camera tab allows you to monitor the bead breaking process of the lower bead. Remember that you can use pinch gestures to zoom in and zoom out.




7.4.2 – Power

The power tab shows you the power system. it allows you to check the ac/dc and dc/dc charging performance. you also have the possibility to switch the inverter on/off. ('off' is recommended when you are not using your ecube for a longer time)




7.4.3 – Page

The html based page tab brings you to the ecube-equipment website as long as connected with the internet (through cell phone or by entering an approved network environment).



7.4.4 – Service

The service tab brings you to the page with manuals and 'how to' videos. It also shows the TeamViewer tab for remote access/support by authorized ecube staff and only after your approval.



The test menu tab helps to quickly identify a possible connection problem between components.

The connect tab helps you to establish a WiFi connection.



The login tab is available to authorized ecube service technicians only.

